


FXEXB EXIT BLADE LEGENDS



Technical Data

Model Variant

FXEXB


Dimensions

318 x 168mm

Installation Guide


1 Release Legend Corners

Use a flat solid object to leverage the legend, or pinch the legend from either side inwards using your hands.




2 Remove Old Legend

Pull the legend out from the top of the exit blade.




3 Locate New Legend Corners

Insert new legend, fitting the top two corners first and pushing the legend up into the exit blade.




4 Locate New Legend Corners

Use your hand or a flat solid object to push the legend into place on the edge.



5 Locate New Legend Corners

Push the opposite edge in the same way as the previous step.



6 Finish Fitting Legend

Push the legend corners in to secure it in place and make sure it lays flat within the exit blade.

